

E.COLI/COLIFORM (10 TESTS)

Product group: **661** Product number: **500002**

The most basic test for bacterial contamination of a water supply is the test for total coliform bacteria. Total coliform counts give a general indication of the sanitary condition of a water supply.



For consistent results, an incubator should be used to culture the samples and the correct temperature.

(UV lamp supplied separately)

Product information

Test Parameters: Coliform and E Coli bacteria tests Qty: 10 tests

Supplied with box containing pack of 10 Coli test bags and 10 ampules of growth media

Used with:

- POTABLE WATER TEST KIT (778419)
- BALLAST CHECK 2 TEST KIT (777848)
- PORTABLE INCUBATOR (777930)
- UV LAMP (777931)

Features

- Simple presence/absence test
- Easy to carry out on board ship
- Can be to test for Potable water and ballast water For Ballast water, dilute the sample by 1 part sample and 9 part deionised water (10 ml sample + 90 ml demin water = 100 ml sample)

Benefits

- Convenient method for measuring and monitoring bacteria and microbial activity in water,
- High quality and consistently reliable results

Documents

[SDoC and MD for IHM](#)