KLÜBER SUMMIT R 200 (PAIL: 20 LTR)

Product group: **683** Product number: **210210**

Product information

Klüber Summit R oils are fully synthetic high-performance lubricants especially developed for heavily loaded ammonia refrigerators and heat pumps. The Klüber Summit R series is characterised especially by its high chemical and thermal stability attained with the carefully selected base oils on the basis of polyalphaolefins. Depending on the system design, Klüber Summit R products might also be successfully used with carbon dioxide (R744). The Klüber Summit R series has a high viscosity index, good shear stability and excellent low-temperature flow behaviour, giving the products large reserve capacity compared with the mineral oils available on the market. Furthermore, the Klüber Summit R series is characterised by low solubility in R717 and R 744. This enables higher film thickness in the lubrication point, contributing to reliable, low-wear compressor operation. The Klüber Summit



Features

- Developed for heavily loaded ammonia refrigerators and heat pumps.
- · Higher refrigerator efficiency due to lower oil content in the refrigerant and very good flow characteristics at low temperatures
- Klüber Summit R products might also be successfully used with carbon dioxide (R744)

Benefits

- · Excellent thermal and chemical stability
- Low product solubility in ammonia
- Separation of the oil/ NH3 mixture in the separator is very good
- Lower operating costs due to long oil filter and oil separator lifetimes

Specification

Physical properties

Appearance	clear
Colour	coulourless
Density at 20°C [g/cm³]	~0.83 g/cm³
Kinematic viscosity of the base oil, DIN 51562 pt. 01/ASTM D-445/ASTM D7042, 100 $^{\circ}$ C [mm²/s]	~ 10 mm²/s
Kinematic viscosity of the base oil, DIN 51562 pt. 01/ASTM D-445/ASTM D7042, 40 °C [mm²/s]	~68 mm²/s

Technical data

Shelf life [months]	36
Viscosity index, DINISO 2909	≥ 130

Performance data

Hash point, DIN EN ISO 2592, Cleveland, open-cup apparatus [°C]	≥ 230 °C
Pour point, DIN ISO 3016 [°C]	≤-51 °C

Documents

SDoC

Directions for use

Drain old oil from the whole circuit of the refrigeration compressor while still warm. We recommend replacing all oil filters and oil separators and completely drain oil traps of the refrigeration circuit. Then refill the compressor with an oil of the Klüber Summit R series.