

Last updated: 16/11/2023 06:28:45

EASYCLEAN CLEANING & DISINFECTANT 10 LTR

Product group: **642** Product number: **778845**

Unitor™ EASYCLEAN™ CLEANING & DISINFECTANT is a highly efficient combined cleaning and disinfection product with outstanding bactericidal performance.



Product information

This product supersedes product no: **623983, 661827, 765107**

Unitor™ EASYCLEAN™ CLEANING & DISINFECTANT is recommended for use in the galley and accommodation areas including refrigeration rooms to eliminate and avoid transmission of bacteria, fungi and viruses.

For US, Unitor™ EASYCLEAN™ CLEANING & DISINFECTANT is REPLACED BY Sanite 128 F. Please see the Safety Data Sheet and Product sheet under 'Documents'.***

Unitor™ EASYCLEAN CLEANING & DISINFECTANT is biodegradable when diluted in water, this means that a fresh solution must be made before every cleaning and disinfection process.

The fact that the Unitor™ EASYCLEAN CLEANING & DISINFECTANT is biodegradable means that it will not give a long term negative effect on the desired microbiological effect produced by the Gamazyme cleaning and treatment products in the drain pipes, tanks or effluent treatment system.

**** Note:** Not suitable for cleaning pots, pans and kitchen gadgets.

Features

- Easy to use cleaning and disinfection product
- Can be used on most hard surfaces
- Phosphate free

Benefits

- Bactericidal, Yeastocidal, Virucidal against Vaccinia, Tuberculocidal, Influenza and BVDV viruses
- VAH, tested according to VAH requirements (German Society for Hygiene and Microbiology, now VAH)
- DVG, Tested according to DVG requirements (8th list, food sector)

Specification

General

Invent Hazard Material (IMO/IEU) classification	C-49
---	------

Physical properties

Density [g/ml]	1,022
Form	Liquid
Odour	Amine odour
Packaging	10L pail
pH	10

Documents

[Cleaning_and_Disinfectant_Covid_4 Letter](#)

[SANITE-128F-Product sheet](#)

[SDoC and MD for IHM](#)

[SANITE-128F-sds](#)

Directions for use

Clean heavy soiled areas with EASYCLEAN™ FLOOR & HARD SURFACE prior to disinfection

Dilute the concentrate of EASYCLEAN™ CLEANING & DISINFECTANT to the correct concentration prior to use through the UNITOR MIXING STATION 4 - 14 OR UNITOR MIXING STATION 4 - 4; 1 : 100 (1,0 %) for galley and other areas and 1,5 : 100 (1,5 %) for hospital

The product is biodegradable and will have reduced effect over time

Apply the cleaning solution with cloth, mop, sponger, spray or by soaking. Allow to work for 15 min for galley and 30 min for hospital, rinse off or allow to air dry.

Areas that can come in contact with food must be rinsed off with fresh water

Floors that are being waxed or polished must be rinsed off with fresh water

Related products

Accessories

778889

EASYCLEAN RE-USABLE BOTTLE C & D(6 pcs per box)

778822

UNITOR CLEANING STATION 2

710450

UNITOR MIXING STATION 4-4

710451

UNITOR MIXING STATION 4-14

Is part of bundle

7788721

EASYCLEAN GALLEY PACK

Is frequently bought together with

778843

EASYCLEAN FLOOR & HARD SURFACE 10LTR

This page is printed from

<https://www.wilhelmsen.com/product-catalogue/products/marine-chemicals/cleaning-chemicals/galley-and-accommodation/easyclean-cleaning--disinfection/>