# KLÜBER SUMMIT RPE 68 (DRUM: 200 LTR)

Product group: **683** Product number: **210185** 

Klüber Summit RPE 32 is a premium synthetic compressor oil designed to deliver excellent wear protection and optimal efficiency in refrigeration systems using modern HFC refrigerants.



#### **Product information**

Klüber Summit RPE series is based on selected polyol esters (POE). They have been designed for use in refrigeration compressors with chlorine-free HFC refrigerants. They have excellent chemical and thermal stability as well as superior lubricity characteristics with steel and aluminium.

#### **Features**

- Formulated with high-quality polyol esters (POE)
- Excellent thermal and chemical stability with HFC refrigerants
- Low pour points for reliable low-temperature performance
- Wide compatibility with refrigerants including R134a,h R-448A, R-449A, R-452A, R-12, R-13, R-22, R-23, R-401 A, R-401 B, R-402 A, R-402 B, R-404 A, R-407 C, R-410 A, R-500, R-502, R-503, R-507 and R-508 B
- Material compatibility with selected elastomers (e.g., NBR >36%, SBR, CR, NR, MMQ)

#### Benefits

- Ensures optimal lubrication and long oil life in demanding refrigeration systems
- Maintains performance under high thermal and chemical stress
- Prevents oil flow issues and supports efficient oil return in cold conditions
- Suitable for various refrigeration applications and refrigerant types
- Reduces risk of seal degradation and leakage, improving system reliability

### **Specification**

#### General

Invent Hazard Material (IMO/EU) classification	2-3
--	-----

# Physical properties

Appearance	clear
Colour	colourless
Density at 20°C [g/cm³]	~0.98 g/cm³
Kinematic viscosity (without solvent), DIN 51562 pt 01/ASTM D-445/ASTM D7042, 40°C [mm²/s]	~68 mm²/s
Kinematic viscosity of the base oil, DIN 51562 pt. 01/ASTM D-445/ASTM D7042, 100 °C [mm²/s]	~ 9.3 mm²/s

#### Dimensions/Weight

Packing Size	200 LTR

#### Technical data

Shelf life [months]	60
Viscosity index, DINISO 2909	≥ 110

#### Performance data

Flash point, DIN EN ISO 2592, Cleveland, open-cup apparatus	s [°C]	≥ 255 °C
Pour point, DIN ISO 3016 [°C]		≤-33 °C

## **Documents**

#### SDoC 210185

## **Directions for use**

Drain as much of the previously used compressor oil from the system as possible, making sure that the oil is drained while still warm. Afterwards clean or change the filters, then recharge with the operational Klüber Summit RPE series lubricant.

This page is printed from

https://www.wilhelmsen.com/product-catalogue/products/speciality-lubricants/kluber-summit-rpe-68-drum-200-ltr.